

**Abbott Rental & Party Store**  
**502 Union Street, Littleton, NH 03561**  
**603-444-6557      www.abbottrental.com**

## SNO-CONE MACHINE Instructions

Be sure equipment is connected to properly grounded 120 volt power supply with 15 amp circuit. Plug directly into a dedicated outlet. Extension cords may create a safety hazard and reduce performance. Be sure outlet accepts 3-prong grounded plug. DO NOT use a 3-prong to 2-prong adapter.

1. Turn POWER switch ON.
2. Fill the ice horn with ice.
3. Press and hold the MOTOR switch to activate blades and begin shaving ice.
4. While holding MOTOR switch down, apply steady downward pressure to the ice pusher.
5. Release the MOTOR switch when finished.
6. Repeat steps 2-5 for additional batches.

**BLADES ARE SHARP AND OPERATE AT HIGH SPEEDS!**

**Please be sure to keep all body parts and any objects such as picks or scoops away from the ice horn while power is on!**

Also included in your rental:

1 Cup Holder  
1 Dipper Spoon  
1 Drain Tube

*You will be charged if  
any of these items  
are not returned.*

Additional Info:

This machine was engineered to shave 500 lbs of cube or chunk ice per hour. Based on the ration that a 1/2 lb of ice will make a 6 oz Sno-Cone, this machine will yield 1000 sno-cones per hour.

One 6 oz sno-cone will take no more than 2 ounces of syrup, 1 ounce will fill the cup 1/2 way, and should be plenty.